

Fig. 1




Fig. 2





Fig. 3



A line drawing of a handheld electronic device, labeled 200. It has a vertical rectangular shape with a small protrusion at the top. The front face features a screen area at the top displaying the text "Select Sport". Below this text is a list of four sports: "Hockey", "Golf", "Bowling", and "Baseball". To the right of the list is a vertical scroll bar with an upward-pointing arrow at the top and a downward-pointing arrow at the bottom. Below the screen area is a keypad consisting of twelve square buttons arranged in a 4x3 grid. The label "200" is positioned to the right of the device, with a line pointing to its right edge.

Fig. 4a

A handheld electronic device 200 is shown. It features a screen 201 at the top, which displays a "Golf Data" form. The form includes five input fields, each with a dropdown arrow: "Player", "Competition", "Hole", "Handicap", and "Score". Below the screen is a keypad consisting of a 4x3 grid of square buttons.

Fig. 4b